



GO BEYOND™

M-11 Mainsail

Quick Tuning Chart

06/2018 Update/NS Japan



BASE SETTING	
MAST RAKE	6110 ± 10 mm (Minus 4900 = 1,21 m)
PRE-BEND	60 - 70 mm
SIDE TENSION	31 - 31.5 by Loose PT-1 gauge (to be measured with chocks) with 2.5mm 1X7 hard wire
MAST STEP	2820 - 2830mm (from back end of the mast groove to back end of the boat)

	1-9 KNOTS	10-16 KNOTS	16-20 KNOTS	20+ KNOTS
(Wante) SHROUDS PIN POSITION	1	2	3	4
	(1,21)	(1,17)	(1,12)	(1,09)
(Mastfall) MAST RAKE	6110 ± 10 mm	6070 ± 10 mm	6000 - 6040 mm	5970 - 6010 mm
(Vorbiegung) PRE-BEND	60 - 70 mm	65 - 75 mm	70 - 80 mm	80 mm +
(Wantenspannung) SIDE TENSION	31 - 31.5		28 - 31	
(Mastkeile) WEDGE (5 mm)*	0 (neutral)	1 - 2 (from neutral)		
(Fockposition) JIB TACK POSITION	Wrinkles (Faltig)	A bit wrinkles smooth by bang on	Tight (Fest)	Very tight (Straff)
(Unterliek) OUTHAUL (from the band) w/ 15 mm space at the tack	20 mm		5 - 10 mm	0 - 5 mm

* The thickness of one wedge is 5mm